

DWZ series Updater

Operating Manual for Windows Vista

Contents

1. Summary	3
2. Preparing	3
3. Install procedure	3
3-1. Folder structure	3
3-2. Installation	4
3.2.1 Installing the Updater	4
3.2.2 Installing the USB Driver	6
4. Update procedure	10
5. Confirmation after updating	12

1. Summary

This manual is a procedure of firmware update of ZTX-B01, ZTX-M01, ZTX-B02RC, ZTX-M02RC, ZRX-C30, ZRX-HR50 and ZRX-HR70.

This manual is explained for procedure of ZRX-HR50, but other equipment is same procedure as ZRX-HR50.

2. Preparation

< Software >

Obtain the Updater file depending on the unit to be updated.

< Others >

Personal Computer

OS: Windows XP SP3, Windows Vista, Windows 7 or Windows 8

USB cable: Type A – Type Micro B (P/N 1-835-226-11 or 1-836-906-11)




3. Install procedure

Install Updater and USB driver to PC.

This item explains about ZRX-HR50, but other equipment is same procedure as ZRX-HR50.

<3.1 Folder Structure>


The folder structure is shown below.



<3.2 Installation>

3.2.1 Installing the Updater


A) Double click ¥ZRX-HR50_Updater_Setup_for_Ver_1_100¥setup.exe.




B) Click [Next>].




C) Click [Next>].



D) Installation will start when [Next >] is clicked.



E) When the following screen is displayed, click [Close]. This completes the setup of the Updater.




3.2.2 Installing the USB Driver


Installation of the USB driver is required when connecting the unit for the first time. It is not required anymore if it is installed once.

- A) Confirmation if the OS in use is 32-bit or 64-bit is required before installation.

Right click [Computer] in the Start menu, and select [Properties].




- B) Check "System type" to confirm if it is 32-bit or 64-bit. Following screen is indicating an OS of 64-bit. Close the Properties once the confirmation is done.




- C) Turn ON the power of the ZRX-HR50.


- D) Connect the PC with the ZRX-HR50 using a USB cable.
Meantime, all of indicators and displays of ZRX-HR50 are turning light off, but this is not a malfunction.
Following screen is displayed, so click on [Locate and install driver software (recommended)].
(If it is not displayed, refer to [Installation of the USB Driver from the Device Manager]).




- E) Click [I don't have the disc. Show me other options].




- F) Click [Browse my computer for driver software (advanced)].




G) Click [Browse...].




H) There are for_32Bit folder and for_64Bit folder in the ¥ZRX-HR50_Updater_Setup_for_Ver_1_100¥USB_Driver folder. Select the folder for the type of OS confirmed in step B), and click [OK].




I) Make sure that [Include subfolders] is selected, and click [Next].




J) Click [Install this driver software anyway].



K) Installation will start.




L) Installation is completed when the following screen is displayed. Restart the PC.




4. Update procedure

This item explains about ZRX-HR50, but other equipment is same procedure as ZRX-HR50.


- A) Turn on the power of ZRX-HR50.
- B) Connect the PC with the ZRX-HR50 using a USB cable.
At this time, indicators and displays of ZRX-HR50 except the power supply LED will turn off, but this is not a malfunction.
- C) Click [All Programs] -> [Sony DWZ Flash Write Tool] -> [ZRX-HR50 Ver. 1.100 Updater] in the Start menu.




- D) Click [Write].




- E) Update will start by clicking on [Yes].




- F) Progress as shown in the following screen is displayed during the update.



G) A dialog is displayed once the update is completed, so click [OK].




H) This completes the update. Click [Exit] to exit from the Updater.



I) Disconnect the USB cable from the ZRX-HR50, and turn off the power of the set.

* When the update fails

Following screen is displayed when the update fails. In such cases, click [Quit], and then restart the Updater to execute the update.




5. Confirmation after updating


This item explains about ZRX-HR50, but other equipment is same procedure as ZRX-HR50.

- A) Turn on the power of ZRX-HR50.
- B) Connect the PC with the ZRX-HR50 using a USB cable.
At this time, indicators and displays of ZRX-HR50 except the power supply LED will turn off, but this is not a malfunction.


- C) Click [All Programs] -> [Sony DWZ Flash Write Tool] -> [ZRX-HR50 Ver. 1.100 Updater] in the Start menu.




- D) Click [Read Version]



- E) Software version will be appeared. After you confirm the software version, click [OK].



- F) Click [Exit]



- G) Pull off the USB cable from ZRX-HR50, and turn off the power of ZRX-HR50.